




DESIGN <i>CP</i>	DRAWN BY <i>CP</i>	DART AEROSPACE USA, INC. PORT HADLOCK, WA	
CHECKED <i>#</i>	APPROVED <i>#</i>	DRAWING NO. DSI 9214	REV. B SHEET 1 OF 1
DATE 02.01.25		TITLE A119 STEP HEIGHT	SCALE NTS
A	01.09.04	NEW ISSUE	
B	02.01.25	ADD NOTE 3	

DART SERVICE INSTRUCTION

TO AMEND INSTALLATION INSTRUCTIONS IIN-D119-675 REV. A
REF. FAA STC: SR00948SE

- 1) FIND THE APPROPRIATE STEP HEIGHT BY LOCATING THE STEP/ CLAMP AS SHOWN BELOW. LOCATE THE FORWARD D3041-3 CLAMP 7.8"-8.2" ABOVE THE CROSSTUBE CUFF. LOCATE THE AFT D3041-1 CLAMP 7.8"-9.0" ABOVE THE CROSSTUBE CUFF. THE DISTANCES GIVEN ARE FROM THE CROSSTUBE CUFF TO THE BOTTOM-MOST CLAMP. CENTER THE ABRASION STRIP UNDER THE CLAMPS, AS SHOWN BELOW.
- 2) WHEN REMOVING THE EXISTING SHORT STEPS, FILL HOLES IN THE CROSSTUBES WITH NAS173826-5 RIVETS (OR EQUIVALENT).
- 3) NOTE THAT IT IS ACCEPTABLE TO LEAVE THE SHORT STEPS ON THE LANDING GEAR PROVIDED THE DART STEP IS INSTALLED IN ACCORDANCE WITH THE DIMENSIONS GIVEN BELOW.



Copyright © 2001 by DART AEROSPACE USA, INC.

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.